




Item No.:SMA038 / SMA038W

Installation guide



M4X12MM A (4PCS)	M5X12MM B (4PCS)	M6X12MM C (3PCS)	M6X10MM D (2PCS)	C6.5X€13X1.8 F (8PCS)
------------------	------------------	------------------	------------------	-----------------------

4X4 Allen key G (1PCS)	5X5 Allen key H (1PCS)
------------------------	------------------------

1	Bottom support 1	1PCS
2	Screw	1PCS
3	Washer	1PCS
4	Butterfly knob	1PCS
5	Bottom support 2	1PCS
6	Knob	1PCS
7	Cable cover 1	1PCS
8	Nylon ties	6PCS
9	Anti-slip rubber 1	4PCS
10	Anti-slip rubber 2	1PCS
11	Anti-slip rubber 3	2PCS
12	Cable cover 2	1PCS



### STEP2-B


Option 2: Install the bracket to the desk

▲ For table thickness:20-90mm

### STEP1

Preparations before installing monitor

1. Make sure there are VESA holes 100x100mm or 75x75mm in the monitor. If not, the mount couldn't be installed.
2. Remove the original fixed base of monitor. Be careful not to scratch the screen.



### STEP3

Attaching the monitor to the plate

### STEP4

Using cord management

### STEP2-A

Option 1: Install the bracket to the desk

▲ For table thickness:20-100mm  
Select right holes according to the thickness of desk