

Product User Guide

Dynamic Seating Component & Upholstery Care Guide

Care & Maintenance Guide - Components

Basic Care

- Do not stand on this product or use this product as a step ladder.
- Use this product only for one person at a time.
- Do not use this chair unless all the bolts, screws and knobs are fully tight and firmly secure.
- Check all bolts, screws and knobs at least every 4 months to ensure they are fully tight and firmly secure.
- If any bolts, screws or knobs are missing or damaged; stop use of the product immediately until this has been repaired using factory authorised parts.
- If any part of the product is missing or damaged, stop use of the product immediately until this has been repaired using factory authorised parts.
- Failure to Follow the above warnings could result in serious injury.

Chrome and Metal Components

- Chromium plated areas can be cleaned with a cloth using methylated spirits. Use with caution and always use the cleaning materials in a ventilated area.
- Lacquered metal can be cleaned with a damp cloth and a mild soap or detergent. The lacquered metal will need to be dried by a different dry cloth.
- Painted aluminium can be cleaned with a soft damp cloth and a mild detergent followed by a clean damp cloth, ensuring that the metalwork is dry afterwards by using a different dry cloth.
- Never use silicon or wax polishes that leave surface residue.
- Never use abrasive powders or scouring pads to clean stubborn marks as this will scratch the components.

Polypropylene Components

- Avoid contact with boiling water, high heat, and abrasives.
- Wash with warm soapy water and apply pressure where necessary, drying afterwards with a clean dry cloth.
- Never use abrasive powders or scouring pads to clean as this will scratch the components.

Mesh Components

- Wash with warm water and apply pressure where necessary, drying afterwards with a clean dry cloth.
- Use a soft brush to remove dirt. Always test in a small inconspicuous area.

Always test on a small inconspicuous area first.

Product User Guide

Dynamic Seating Component & Upholstery Care Guide

Care & Maintenance Guide - Upholstery

Fabric Upholstery

Do:

- Vacuum on a weekly basis to help eliminate dirt before it comes embedded in the fibres.
- A light brushing helps to remove dirt but always use a soft bristled brush.
- Ensure spots and stains are cleaned as quickly as possible with a clean towel and blot gently.
- Try and clean upholstery at the same time to prevent irregular fading.
- Clean on a regular basis with a suitable cleaner.

Don't:

- Never apply bleach, ammonia, alkali or strong acids to wool upholstery.
- Rub the upholstery with a towel or cloth, only blot gently.

Vinyl Upholstery

Do:

- Soak up spills as quickly as possible using a dry absorbent cloth.
- Clean regularly with warm soapy water.
- Rinse after cleaning with clean water.
- Clean persistent or heavily soiled stains with a soft brush.
- Disinfect with diluted chlorinated solutions or cleaners with low concentrations of alcohol.

Don't:

- Leave soap or cleaning fluid residues on the vinyl surface (especially alcohol based).
- Steam clean the product.
- Use stain removers and polish containing solvents or abrasive tools and cleaning agents.

Leather/ Bonded Leather Upholstery

Do:

- Wipe down bonded leather furniture with a clean, damp cloth.
- Dry it with a different clean dry cloth until it is completely dry.
- Ensure spills and stains are cleaned as quickly as possible with a clean towel and blot gently.

Don't:

- Use soap or abrasive cleaners as they may damage the finish.

Always test any cleaners on a small inconspicuous area first.